

Replacing Snap Hooks


Materials Needed:

Halyard (rope)

Metal or Nylon (plastic) Snap Hook

Optional - Rubber Snap Hook cover

(Typically used for metal snap hooks to prevent clanking noises)



STEP 1:

Pinch halyard and feed rope through smaller end of rubber snap hook cover



STEP 4:

Pull halyard tight



STEP 2:

Feed rope through the bottom loop of the metal or nylon snap hook



STEP 5:

Pull rope tight until the snap hook is pulled into the snap hook covers.



STEP 3:

Pull loop of the halyard over the top clasp of snap hook

